

Read these safety instructions before using the device and store them for possible future reference.

- Persons, who have not read this manual, should not use this device.
- The device is not intended for use by persons (including children) with reduced physical, sensory or mental capacity.
- Children should be monitored to ensure that they do not play with the device.
- The device should not be exposed to dripping or splashing water.
- Open flame sources, such as candles, should not be placed near the device.
- The device is intended for use only in a temperate climate.
- Make sure that your smartphone is completely secured to your selfie-stick.
- Avoid selfie-stick usage in the following locations and situations: crowded areas, public transportation, while driving any vehicle, riding on bicycle, roller-skates, skate-boards or during any other motion process, nearby animals and around dangerous places such as cliffs, roads, rails, exposed electric wires, landslide areas and etc.
- Never make a phone/ video call when the smartphone attached to a selfie-stick.

קראו את הוראות הבטיחות לפני השימוש במכשיר ואכסנו אותם לעיון עתידי.

- אין להשתמש במוצר זה לפני קריאת הוראות הבטיחות.
- המוצר אינו מיועד לשימוש על ידי אנשים (כולל ילדים) בעלי מוגבלות פיזית או נפשית.
- יש להשגיח על ילדים בעת שימוש במוט הסלפי ולוודא כי אינם משחקים עימו.
- אין לחשוף את המוצר למים, כולל נתזי מים.
- אין למקם את המוצר סמוך למקור אש גלוי, כדוגמת נרות.
- המוצר מיועד לשימוש במזג אויר יבש בלבד ובטמפר' שבין 35-5 מעלות צלזיוס.
- יש לאבטח את הטלפון באופן מיטבי לתפס הטלפון שבמוט הסלפי.
- אין להשתמש במוט הסלפי במקומות ובמצבים הבאים:
- באזורים הומי אדם, בתחבורה ציבורית, בעת נהיגה בכלי רכב, ברכיבה על אופניים או גלגליות או סקייטבורד או במהלך כל תנועה מהירה, בצמוד לבעלי חיים, במקומות מסוכנים בהם אפשר להיפגע כתוצאה מחוסר תשומת לב (מצוק, כביש, פסי רכבת, חוטי חשמל חשופים, אזורי אסון, אזורי מפולת וכד').
- אין לבצע שיחת טלפון / וידאו כאשר הטלפון מחובר למוט הסלפי.

1. Thank you for purchasing a Barkan's selfie-stick.
2. This product is covered by a limited warranty to the original purchaser, only that this product is free from defects in workmanship and materials for **TWO YEARS** from the date of purchase.
3. This warranty excludes the AUX cable and electronics parts, which are covered with **ONE YEAR** of Limited Warranty from the date of purchase.
4. The warranty does not cover any defects or costs caused by the damages through normal wear and tear, water damages, alteration, misuse, neglect, accident, service by anyone other than an authorized service center, or force majeure.
5. Upon verification of the product and purchase date, this product will be replaced when returned with proof of purchase.
6. For all warranty claims, the product must be returned to the store from which the product was bought.

1. אנו מודים לך על רכישת מוט סלפי מתוצרת ברקן.
2. מוצר זה מכוסה על ידי אחריות מוגבלת **לשנתיים** ממועד הרכישה. האחריות תקפה עבור הרוכש המקורי ומתייחסת לתקינות ושלמות חלקי המוצר.
3. אחריות זו אינה כוללת את כבל ה-AUX וכן את חלקי האלקטרוניקה, אשר מכוסים ע"י אחריות מוגבלת **לשנה** ממועד הרכישה.
4. האחריות אינה מכסה כל פגם או נזק שנגרם כתוצאה מבלאי סביר, נזקי מים, שינוי המוצר, שימוש לרעה, הזנחה, תאונה, שירות על ידי מי שאינו מורשה לכך ע"י חברת ברקן או כוח עליון.
5. לאחר אימות פרטי המוצר ותאריך רכישה המוצר יוחלף כנגד תעודת רכישה.
6. במקרה של תביעת אחריות, יש להחזיר את המוצר לחנות ממנה המוצר נקנה.